



Reroofing Requirements

Building permit & inspections are required

**A licensed contractor is required unless work is to be completed by the homeowner.*

Inspections:

Call for an inspection when project has been completed.

Rough-In:

Photos taken of roof deck ***before and after*** installation of icedam protection and underlayment. Icedam protection must extend 24" inside exterior wall line.

Final:

Call to schedule final inspection when work is completed. Provide photos of installed icedam protection and underlayment as well as shingle manufacturers' installation instructions. If emailing photos, you will be instructed at the time of scheduling, which email to use for photos.

David.Ding@co.wright.mn.us

Michael.Woodford@co.wright.mn.us

(be sure to provide the permit number and address in the e-mail)

To schedule inspections, please have permit number, owner's name, and project address ready before calling:

763-682-7338