

FROM TYPE	BEARING	DISTANCE	TO	NORTHING	EASTING
-----------	---------	----------	----	----------	---------

LIST POINTS POINT	NORTHING	EASTING	ELEVATION	DESCR
11	242870.192515	461059.880965		
13	244224.033168	461059.465902		
15	245577.873820	461059.050839		
17	246932.329728	461049.001126		
19	248286.785637	461038.951412		
31	242862.636746	462388.093106		
33	244216.160683	462384.952263		
35	245569.684620	462381.811420		
37	246922.807342	462373.856325		
39	248275.930063	462365.901230		
51	242855.080977	463716.305247		
53	244208.288199	463710.438624		
55	245561.495420	463704.572001		
57	246913.284955	463698.711524		
59	248265.074490	463692.851047		
69	248255.400275	464814.825297		
71	242854.291489	465038.908624		
73	244203.788099	465034.857812		
75	245553.284710	465030.807001		
76	246142.992191	465031.162654		
77	246896.615401	465031.617166		
78	246894.838502	465173.698914		
79	248249.741713	465032.433238		
91	242853.502000	466361.512000		
93	244199.288000	466359.277000		
94	244199.288000	466359.277000		
95	245545.074000	466357.042000		
97	246880.066463	466354.878305		
98	247177.140573	466354.396821		
99	248214.916699	466371.678003		
100	246416.108309	465739.313860		
102	246835.990463	465183.056377		
103	247226.285299	465120.995356		
104	247673.110544	464949.577488		
105	247964.885389	464709.681570		

START				11	242870.193	461059.881	
11	INV N	0-01-03.2	W	2707.681	15	245577.874	461059.051
15	INV N	0-25-30.4	W	2708.986	19	248286.786	461038.951
19	INV S	89-31-52.6	E	2653.988	59	248265.074	463692.851
59	INV S	89-30-21.5	E	1122.016	69	248255.400	464814.825
69	INV S	88-30-37.6	E	1557.379	99	248214.917	466371.678
99	INV S	0-57-14.4	W	1037.920	98	247177.141	466354.397
98	INV S	0-05-34.3	E	1632.069	95	245545.074	466357.042
95	INV S	0-05-42.6	E	2691.576	91	242853.502	466361.512
91	INV N	89-57-56.9	W	2645.207	51	242855.081	463716.305
51	INV N	89-40-26.6	W	2656.467	11	242870.193	461059.881
START				51	242855.081	463716.305	
51	INV N	0-14-54.2	W	2706.440	55	245561.495	463704.572
55	INV N	0-14-54.2	W	2703.604	59	248265.074	463692.851
START				15	245577.874	461059.051	
15	INV S	89-38-43.0	E	2645.572	55	245561.495	463704.572
55	INV S	89-38-43.0	E	2652.521	95	245545.074	466357.042

POINT-POINT ANGLES								
ANGLE	51 -	11 -	15:	C.W.	269-39-23.4	C.C.W.	90-20-36.6	2707.681
ANGLE	11 -	15 -	19:	C.W.	179-35-32.8	C.C.W.	180-24-27.2	2708.986
ANGLE	15 -	19 -	59:	C.W.	270-53-37.8	C.C.W.	89-06-22.2	2653.988
ANGLE	19 -	59 -	69:	C.W.	180-01-31.1	C.C.W.	179-58-28.9	1122.016
ANGLE	59 -	69 -	99:	C.W.	180-59-43.9	C.C.W.	179-00-16.1	1557.379
ANGLE	69 -	99 -	98:	C.W.	269-27-52.0	C.C.W.	90-32-08.0	1037.920
ANGLE	99 -	98 -	95:	C.W.	178-57-11.3	C.C.W.	181-02-48.7	1632.069
ANGLE	98 -	95 -	91:	C.W.	179-59-51.8	C.C.W.	180-00-08.2	2691.576
ANGLE	95 -	91 -	51:	C.W.	270-07-45.7	C.C.W.	89-52-14.3	2645.207
ANGLE	91 -	51 -	11:	C.W.	180-17-30.2	C.C.W.	179-42-29.8	2656.467